

How to set up OBS Virtual Cam with AViPAS cameras:

- Make sure your computer is configured according to the camera: open IE/ Chrome browser, and make sure you can log into the camera.

- Download OBS Virtual Cam:

<https://www.dropbox.com/s/2wwbf8632e35yce/obs-virtualcam-2.0.5-Windows-installer.exe?dl=0>

- Open OBS Studio:

1. "Sources" -> "+" -> "Media Source" -> "Create new" Ok -> UNCHECK "Local File" -> Input:
rtsp://192.168.5.163/live/av0

You should be able to see the video image in the preview window. Please note the 192.168.5.163 in the rtsp line is the current IP address of the camera.

*AV-1560/ AV-1071: rtsp://192.168.100.88/1

*AV-1080/ AV-1280 / AV-1250/ AV-1362 Series: rtsp://192.168.5.163/live/av0

*AV-2020/2010: rtsp://192.168.1.188:554/stream/main

2. Selecting Tools -> VirtualCam
3. Press "start" button and close dialog
4. Open your 3rd party program and choose "OBS-Camera" as a Video input